

Wood quality parameters to assess potential of poplar and willow clones for short rotation coppice bioenergy plantations

Joris Van Acker¹, Jan Van den Bulcke¹, Nele Defoirdt¹,
Marijke Steenackers², Boudewijn Michiels²

¹UGent – lab / ²INBO

Belgium July 21st



International Poplar Symposium VI - July 2014
Vancouver, British Columbia, Canada




Collaboration INBO & UGent/Woodlab

Poplars and willows at INBO



Link with 'Union Allumettière' – 'Swedish Match Group'



Geraardsbergen /Grammont

Poplar Institute 1948  Victor Steenackers

Poplars and willows at UGent/Woodlab



Center for study of Biomass 1982



IR areal

Collaboration INBO & UGent/Woodlab

Poplars and willows at INBO



Now integrated in “The Research Institute for Nature and Forest” (INBO), a scientific institute of the Flemish Government

Poplars and willows at UGent/Woodlab



Intensified interaction with poplar industry: Xylindus vzw

Long-lasting interaction with INBO both direct contract research and international cooperation, e.g. EU projects/networks



MATERIALS versus BIOENERGY

Poplars and willows for bioenergy – specific clones and cultivation/harvesting



Multipurpose applications? Integrated wood transformation or specific production for bioenergy



MATERIALS and / or ENERGY

- Contradictions in selection and breeding?
- Cellulose or lignin... mechanical properties, pulp, bioenergy,...
- Bioenergy... via second generation biofuels & microbiology...
Focus on carbohydrates... Lower lignin content?
- Bioenergy... direct combustion, pyrolysis,... Higher energy
content... Higher lignin content?
- Can we combine or should we have specific, separate strategies?


TOOLS to check WOOD QUALITY


HIGH THROUGHPUT SYSTEMS

- Micro CT scanner: structure, density
- Chemistry (cellulose, tension wood)
- Energy content, conversion potential

Possible to optimise all?







MEAN / AVERAGE - ENERGY WOOD QUALITY


Belgian * poplar clone	Density (kg/m ³)	Green moisture content (%)	HHV of SRC (MJ/kg)	Bark,...
Muur	332	170	19.5	
Vesten	451	168	19.4	
Oudenberg	363	161	19.2	
Grimminge	452	137	19.5	
Bakan	420	156	19.4	
Skado	400	157	19.4	

* Introduced by INBO

Bomb calorimeter



Density



**High throughput phenotyping
including variability, patterns,...**


(1) structure – density

(2) lignin/(hemi-)cellulose


Analysis of microstructure & density

X ray Tomography - NanoWood

EU Projets Noveltree & Trees4future




X ray Tomography - Typical high resolution CT setup




Linking with (micro)density

X-ray computed tomography:


- Acquire series of radiographies at different angles
- Combine to obtain full 3D representation
- Non-destructive High-resolution tomography: down to 400 nm



$G_1 \times E$



$G_2 \times E$




***Macro-density ignores & integrates
 $G \times E$ interactions at smaller time-scales***

Calorimetric properties - *macrochemicals*

EU Projets Noveltree & Trees4future


Short-Wave InfraRed (SWIR)




Coupled DSC-TGA



Spectral




*Short-Wave InfraRed
(SWIR)*







Coupled DSC-TGA



TGA
Thermo
Gravimetical
Analysis




DSC
Differential
Scanning
Calorimetry



Deconvolution - macrochemicals



Calibration of SWIR



Combined *microdensitometry* - *macrochemicals*

EU Projects NovelTree & Trees4future



Case study using different poplar clones

Disc material

Origin:

INRA (Institut National de la Recherche Agronomique)


Orléans – France

Responsible: Catherine BASTIEN




Microdensitometry

Nanowood CT scanner



Macrochemical


NIRS & DSC-TGA



Specimen 1: ringshaped tension wood (one side)


Microdensitometry

Nanowood CT scanner



Macrochemical


NIRS & DSC-TGA



Specimen 2: semi-uniform


Microdensitometry

Nanowood CT scanner



Macrochemical

NIRS & DSC-TGA





Specimen 3: shift early juvenile - juvenile – mature wood

Microdensitometry

Nanowood CT scanner

Macrochemical

NIRS & DSC-TGA






Specimen 4: earlywood – latewood pattern / low orientation

3 complementary techniques

- ❖ DSC-TGA: energy / approx. chemical composition
- ❖ Hyperspectral NIR imaging: via PLS any property
-> energy & chemical composition
- ❖ X-ray tomography: density, porosity, dimensions,
moisture content, microstructure

**—————→ Fast characterization of woody biomass
linked to spatial patterns**



Joris.VanAcker@UGent.be
Jan.VandenBulcke@UGent.be
Nele.Defoirdt@UGent.be

www.woodlab.be
www.ugct.ugent.be
www.inCT.be (spin-off)
www.xre.be (spin-off)



Joris Van Acker, Luc Van Hoorebeke, Patric Jacobs, Veerle Cnudde, Bert Masschaele, Manuel Dierick, Jelle Vlassenbroeck, Yoni De Witte, Elin Pauwels, Matthieu Boone, Denis Van Loo, Loes Brabant, Marijn Boone, Tim De Kock, Pieter Vanderniepen, Jan Dewanckele, Dries Vansteenkiste, Nele Defoirdt, Imke De Windt, Wannas Hubau, Maaïke De Ridder, Jan Van den Bulcke

X-ray tomography and coupled DSC-TGA

EU project for funded research access – **Trees4Future** project
<http://www.trees4future.eu/transnational-accesses.html>

